


TRS-JACK

TRS-JACK

DIN

DIN



RCA

RCA

XLR/F

XLR/M

LITTLE HELPER SERIES
LH-085
 CABLE TESTER

SPEAKER

SPEAKER

Jack	XLR M/F	RCA	Speaker
1 = Sleeve	1 = ①	1 = Screen	1 = -1
2 = Tip	2 = ②	2 = Hot	2 = +1
3 = Ring	3 = ③		3 = -2
			4 = +2

Illuminated pair of LEDs indicate corresponding pins connected.
 Ground LED illuminated indicates connection (short circuit) from pin to shell.
 Rotary switch fully clockwise : bright LED indicates charged battery.
 Banana: continuity tester with beeper & LED