




MIDI USB MP3 PCconnect ID3tag MASTER TEMPO

No. 10602299

OMNITRONIC DJS-2000 DJ Player

Media player and MIDI controller for DJs + One DJ Start software



USB MP3 SDHC ID3tag ANTISHOCK

No. 11046035

OMNITRONIC XMT-1400 Tabletop CD Player

DJ player for CD, USB and SD



USB MP3 MASTER TEMPO ANTISHOCK 19"

No. 10602409

OMNITRONIC CMP-2000 Dual CD/MP3 Player

Dual CD/MP3 player for DJs



USB MP3 ID3tag MASTER TEMPO 19"

No. 10602411

OMNITRONIC CMP-2001 Single CD/MP3 Player

CD/MP3 player with recording function for DJs



ANTISHOCK 19"

No. 11046001

OMNITRONIC XCP-1400 CD Player

Single CD player



MP3 ANTISHOCK ID3tag 19"

No. 11046005

OMNITRONIC XMP-1400 CD/MP3 player

CD and MP3 player



USB MP3 SDHC ANTISHOCK ID3tag 19"

No. 11046010

OMNITRONIC XDP-1400 CD/MP3 player

CD and MP3 player for CD, USB and SD



USB MP3 ID3tag 19"

No. 11045011

OMNITRONIC DMP-103RDS Media Player

CD/MP3 player with FM RDS tuner and USB port



ANTISHOCK 19"

No. 11046020

OMNITRONIC XCP-2800 Dual CD Player

Dual CD player



USB MP3 SDHC ANTISHOCK ID3tag 19"

No. 11046030

OMNITRONIC XDP-2800 Dual CD/MP3 Player

Dual CD and MP3 player for CD, USB and SD