



No. 11041126
PSSO K-121 Subwoofer 400W
 Pro PA bassreflex sub, 12" woofer, 400 W RMS, 8 ohms



No. 11041128
PSSO K-102 Subwoofer 600W
 Pro PA bassreflex sub, 2 x 10" woofer, 600 W RMS, 4 ohms



No. 11041130
PSSO K-122 Subwoofer 800W
 Pro PA bassreflex sub, 2 x 12" woofer, 800 W RMS, 4 ohms



No. 11041131
PSSO K-151 Subwoofer 500W
 Pro PA bassreflex sub, 15" woofer, 500 W RMS, 8 ohms



No. 11041132
PSSO K-152 Subwoofer 1000W
 Pro PA bassreflex sub, 2 x 15" woofer, 1000 W RMS, 4 ohms



No. 11041136
PSSO K-181 Subwoofer 1000W
 Pro PA bassreflex sub, 18" woofer, 1000 W RMS, 8 ohms



No. 11041140
PSSO K-182 Subwoofer 2000W
 Pro PA bassreflex sub, 2 x 18" woofer, 2000 W RMS, 4 ohms



No. 11041142
PSSO K-211 Subwoofer 1600W
 Pro PA horn-loaded sub, 21" woofer, 1600 W RMS, 4 ohms



No. 11043560
PSSO SUB-2180 Subwoofer
 Pro PA horn-loaded sub, 2 x 18" woofer, 1600 W RMS, 4 ohms

