



Best.-Nr. 11041126
PSSO K-121 Subwoofer 400W
 Profi-PA-Bassreflex-Subwoofer, 12" Woofer, 400 W RMS, 8 Ohm



Best.-Nr. 11041128
PSSO K-102 Subwoofer 600W
 Profi-Bassreflex-Subwoofer, 2 x 10" Woofer, 600 W RMS, 4 Ohm



Best.-Nr. 11041130
PSSO K-122 Subwoofer 800W
 Profi-Bassreflex-Subwoofer, 2 x 12" Woofer, 800 W RMS, 4 Ohm



Best.-Nr. 11041131
PSSO K-151 Subwoofer 500W
 Profi-Bassreflex-Subwoofer, 15" Woofer, 500 W RMS, 8 Ohm



Best.-Nr. 11041132
PSSO K-152 Subwoofer 1000W
 Profi-Bassreflex-Subwoofer, 2 x 15" Woofer, 1000 W RMS, 4 Ohm



Best.-Nr. 11041136
PSSO K-181 Subwoofer 1000W
 Profi-Bassreflex-Subwoofer, 18" Woofer, 1000 W RMS, 8 Ohm



Best.-Nr. 11041140
PSSO K-182 Subwoofer 2000W
 Profi-Bassreflex-Subwoofer, 2 x 18" Woofer, 2000 W RMS, 4 Ohm



Best.-Nr. 11041142
PSSO K-211 Subwoofer 1600W
 Profi-Subwoofer (horngeladen), 21" Woofer, 1600 W RMS, 4 Ohm



Best.-Nr. 11043560
PSSO SUB-2180 Subwoofer
 Profi-Subwoofer (horngeladen), 2 x 18" Woofer, 1600 W RMS, 4 Ohm

