

SHP-777BT Bluetooth Headphones



User Manual

TECHNOLOGY DESIGNED FOR PLEASURE WWW.OMNITRONIC.DE

Your new SHP-777BT Bluetooth Stereo Headphones


- Wireless bluetooth stereo headphones listen to audio from mobile Bluetooth devices like smartphones, tablets and notebooks
- Operating range up to 10 m.
- Long operating time of up to 10 hours via integrated battery
- Integrated hands-free calling and microphone
- Volume, music, and calls control buttons answer calls and control
- 3D sound simulation delivers outstanding sound effect with unmatched quality and reality, particularly rich in detail with digital audio tracks
- 40 mm speakers for powerful bass-driven sound
- Light-weight design with well-padded, adjustable headband
- Ontimal wearing comfort for long music sessions.
- Space-saving design with collapsible ear-pieces
- . 30 days standby mode
- 3.5 mm audio input connects any non-Bluetooth device or in case the battery runs down
- Incl. USB charging cable and 3.5 mm jack cable

Accessories

Micro USB charging cable

3.5 mm iack cable

User manual



4 3.5 mm audio jack

Volume Up /Previous Track Z T Increase Volume Go to Next Track

6 Microphone

8 Adjustable Headband

LED indicator

Charging the Headphones

Use the micro USB cable and connect the headphones to your computer or adaptor device made for USB charging. The red LED indicator will turn on when the headphones are charging. The red LED light will turn off when headphones are fully charged

Pairing

- Make sure your phone, computer or music device is turned on and within 1 meter of each other.
- A Hold down the multifunction On/Off button (1) for about 3 seconds until the LED light starts to flash BLUE quickly.
- 3 Activate the Bluetooth feature on your phone or device and set it to search for Bluetooth devices (Discoverable).
- 4 Select "SHP-777" from the list of found devices.
- **5** If necessary, enter passcode "0000" to pair and connect the headphones to your device.
- Once successfully paired, the LED light will flash BLUE once every few seconds.

Playback / Controls

- Press the multifunction button Play/Pause (1) to start and pause
- Press button 5 to skip forward to next track. Press and hold down button to increase volume
- 3 Press button 2 to go back to previous track. Press and hold down the button to decrease volume.

Note: The controls will not function when charging.

- To answer an incoming call, press the Multifunction Play/Pause
- 2 To end the call, press the same button again.
- 3 To decrease or increase the volume during the call, press and hold down button 2 or button 5

Power On

Press and hold the Multifunction button (1) to turn the headphones on. The LED indicator will flash BLUE when the headphones are on.

Power Off

Press and hold the Multifuction button (1) to turn the headphones off. The LED indicator will stop flashing when off.

Using the Headphones in Passive Mode (Wired)

You can use the headphones as a wired headphone to save battery. Simply connect one end of the 3.5 mm cable to the bottom of the ear piece and the other end to your phone or device.

Note: Inserting the audio cable disables wireless functionality.



Transportation

For good transmission quality and best possible comfort, the headband should be adjusted to properly fit your head. To do so. adjust the headband through its snap-in locking mechanism. For space-saving transportation, the earcups can be folded and tucked between the headband.

How to fold the headphones:



The headphones should be cleaned from time to time. Please use a soft lint-free and moistened cloth. Never use alcohol or solvents!

Important Safety Information

- Always turn down the volume control before plugging the headphones into a sound source
- Turn up the volume control only far enough to hear properly.
- If your are connecting these headphones to an airplane's sound system, listen at low levels so that loud messages from the pilot do not discomfort.
- Ringing in the ears may indicate that the volume level is too high.
- Do not use these headphones where vehicular traffic is present, or in any other activity where a failure to hear surrounding sounds could be dangerous.
- Ambient temperature-5 45° C.
- Rechargeable batteries are hazardous waste which needs to be disposed of appropriately. If the device is to be disposed, the battery has to be removed first. Take it to a local recycling plant for a disposal which is not harmful to the environment. Do not dispose of rechargeable batteries into household waste!
- Maintenance and service operations are only to be carried out by authorized dealers.
- Damage, caused by manual modifications on the product is not subject to warranty. If this product is used for other purposes than originally intended or if it is not correctly connected, the product may suffer damage and the guarantee becomes void.

Technical Specifications

Power supply:	via built-in lithium polymer rech. battery (450 mAh) or 5 V DC via USB
Bluetooth version:	3.0
Profiles:	A2DP 1.2, AVRCP 1.0
Range:	10 m
Carrier frequency:	2.4-2.4835 GHz
Charging time:	max. 2.5 hours
Playing time:	7.5 hours
Standby:	up to 45 days
Status indicators:	blue LED for power and pairing red LED for charging
Speaker:	40 mm
Frequency range:	20 Hz - 20 kHz
Impedance:	32 ohms
Sensitivity:	110 (± 5 dB)
Max. input power:	10 mW
Distortion:	< 1 % (at 1 kHz)
Connections:	3.5 mm stereo jack, micro USB
Weight:	183 g

Item no. 14000340/14000341 Subject to change without prior notice



@2015 00089742 V1 0 www.omnitronic.de

