

No. 26702052.....4 cross connections
 No. 26702058.....2 cross connections
DIMAVERY SV-1 Keyboard Stand with Clamp Lock
 Stable Keyboard stand



No. 26702061.....SL-5, bolt with spring
 No. 26702062.....SL-3, quick-lock
DIMAVERY SL Keyboard Stand
 Keyboard stand



No. 26702080
DIMAVERY Microphone Arm for Keyboard Stands
 Extension for keyboard stands



No. 26600060
DIMAVERY Stand for Clarinet or Flute, black
 Stand for clarinet and flute black




 No. 8331207H.....white
 No. 8331207K.....black
EXPAND XTOW Deskcover one side open white
 For tables up to 2.4x1m




No. 8331207C
EXPAND XPSC2 Screen 150x200cm
 Projection screen




 No. 83312082.....white, one side
 No. 83312084.....white, three sides
 No. 83312086.....black, three sides
EXPAND Cover
 Cover for lighting stands up to 3.1 m




 No. 83312083.....white
 No. 83312087.....black
EXPAND XPS2GW Tripod Cover two sides
 Cover for lighting stands up to 3.1 m




 No. 83312090.....one side
 No. 83312092.....two sides
 No. 83312093.....one side, stretchable 0.8 - 1.2 m
 No. 83312094.....three sides
 No. 83312071.....Mounting Disc
EXPAND XPS1KW Tripod Cover white
 Cover for speaker stands up to 2.2 m




 No. 83312104
EUROPALMS Tripod Cover white three-sides
 Cover for lighting stands



 No. 83312100.....white
 No. 83312101.....black
EXPAND XPXSW Cover for Keyboard Stand
 Flexible keyboard stands cover



 No. 83312102
EUROPALMS Cover for Keyboard Stand white
 Flexible keyboard stands cover