

## Speaker bag SBD

- No. 30129700 ..... 10, for KPA-210(A) and KB-210(A)
- No. 30129710 ..... 12, for KPA-212(A) and KB-212(A)
- No. 30129720 ..... 15, for KPA-215(A) and KB-215(A)

- Applicable for KPA-210, KPA-210A and KB-210, KB-210A
- Made of easy-care artificial textile with soft inner lining
- Protection against knocks, blows and splash water
- Openings for stand and handle with velcro fasteners and zippers
- With additional cable bag
- Color: black



## Speaker bag SBD PRO

- No. 30129705 ..... 10, for KPA-210(A) and KB-210(A)
- No. 30129715 ..... 12, for KPA-212(A) and KB-212(A)
- No. 30129725 ..... 15, for KPA-215(A) and KB-215(A)

- Applicable for KPA-210, KPA-210A and KB-210, KB-210A
- Made of easy-care artificial textile with soft inner lining
- Protection against knocks, blows and splash water
- Speaker can remain in the bag during operation
- Openings for stand and handle with velcro fasteners and zippers
- Sound-transparent front of meshed fabric with zipplable cover
- Color: black



## Speaker bag for PAS

- No. 30129730 ..... PAS-208II
- No. 30129731 ..... PAS-210II
- No. 30129732 ..... PAS-212II
- No. 30129733 ..... PAS-215II

- Applicable for PAS-208 II
- Made of easy-care artificial textile with soft inner lining
- Protection against knocks, blows and splash water
- Opening for connectors with velcro fasteners
- Opening for stand
- Color: black

