



OMNITRONIC Speaker cable XLR 2x1.5

No. 3022069L.....	1.5 m
No. 3022069M.....	3 m
No. 30220700.....	5 m
No. 30220710.....	10 m



OMNITRONIC Speaker cable XLR 2x2.5

No. 30220720.....	1.5 m
No. 30220722.....	3 m
No. 30220724.....	5 m



OMNITRONIC Adaptercable 2xXLR(M)/2xRCA

No. 3022522B.....	1 m
No. 3022522C.....	1.5 m
No. 3022522D.....	3 m
No. 3022522E.....	6 m



OMNITRONIC Adaptercable 2xXLR(M)/Jack stereo

No. 3022519G.....	1.5 m
-------------------	-------



OMNITRONIC Adaptercable RCA/XLR(F)

No. 30224014.....	2 m
-------------------	-----



OMNITRONIC Adaptercable RCA/XLR(F)

No. 30224025.....	0.6 m
No. 30224028.....	2 m
No. 30224030.....	5 m



OMNITRONIC Adaptercable 3.5 Jack 90°/2xRCA

No. 30225008.....	0.5 m
No. 30225009.....	1 m
No. 30225010.....	1.5 m
No. 30225012.....	3 m



OMNITRONIC Adaptercable USB/2xMIDI

No. 30225025.....	1.5 m
No. 30225026.....	3 m
No. 30225028.....	5 m



OMNITRONIC Adaptercable XLR(F)/Jack

No. 30225080.....	0.3 m
-------------------	-------



OMNITRONIC Adaptercable XLR(M)/Jack mono

No. 30225085.....	30 cm
No. 30225090.....	80 cm



OMNITRONIC Adaptercable 3.5 Jack/2xRCA

No. 3022514C.....	0.5 m
No. 3022514E.....	1 m
No. 30225151.....	1.5 m
No. 30225149.....	3 m
No. 30225148.....	6 m



OMNITRONIC Adaptercable 3.5 Jack/2xRCA

No. 30224200.....	1.5 m
No. 30224205.....	3 m
No. 30224210.....	5 m



OMNITRONIC Adaptercable RCA/Jack

No. 30225111.....	0.9 m
-------------------	-------



OMNITRONIC Adaptercable RCA/Jack

No. 30225118.....	0.9 m
No. 30225120.....	2 m
No. 30225165.....	6 m



OMNITRONIC Adaptercable RCA/XLR(M)

No. 30225121.....	0.6 m
No. 30225123.....	0.9 m
No. 30225125.....	2 m



OMNITRONIC Adaptercable RCA/XLR(M)

No. 30225122.....	0.6 m
No. 30225124.....	0.9 m
No. 30225126.....	2 m
No. 30225166.....	5 m