



- PSSO Patch Cord Speakon/Speakon S 1m**
- No. 30227890..... 4pin
- No. 30227891..... 2pin



- PSSO Speaker cable Speakon 4x2.5**
- No. 30227930..... 5 m
- No. 30227931..... 10 m
- No. 30227932..... 15 m



- PSSO Speaker cable Speakon 2x1.5**
- No. 3022790A..... 1,5 m
- No. 3022790B..... 3 m
- No. 3022790C..... 5 m
- No. 3022790F..... 10 m
- No. 3022790H..... 15 m



- PSSO Speaker cable Speakon 2x4**
- No. 3022791A..... 1,5 m
- No. 3022791C..... 3 m
- No. 3022791E..... 5 m
- No. 3022791G..... 10 m
- No. 3022791H..... 15 m
- No. 3022791J..... 20 m



- PSSO Combi cable PowerCon/XLR**
- No. 30227798..... 3 m
- No. 30227800..... 5 m
- No. 30227802..... 10 m



- PSSO Speaker cable Speakon 2x2.5**
- No. 3022790K..... 1,5 m
- No. 3022790M..... 3 m
- No. 30227910..... 5 m
- No. 30227912..... 10 m
- No. 30227915..... 15 m
- No. 30227916..... 20 m



- OMNITRONIC Speaker cable Speaker 2x1.5**
- No. 3022102M..... 1,5 m
- No. 3022105M..... 3 m
- No. 3022110M..... 5 m
- No. 3022120M..... 10 m
- No. 3022130L..... 15 m
- No. 3022130M..... 20 m



- OMNITRONIC Speaker cable Speaker 2x2.5**
- No. 3022102N..... 1,5 m
- No. 3022105N..... 3 m
- No. 3022110N..... 5 m
- No. 3022120N..... 10 m
- No. 3022130N..... 15 m
- No. 3022130P..... 20 m
- No. 3022130R..... 25 m



- OMNITRONIC Speaker cable Speaker 2x4**
- No. 3022103N..... 1,5 m
- No. 30221200..... 5 m
- No. 30221300..... 10 m



- OMNITRONIC Speaker cable Jack 2x1.5**
- No. 3021169M..... 1,5 m



- OMNITRONIC Adaptercable Speaker(F)/XLR(M)**
- No. 30225590..... 1 m



- OMNITRONIC Adaptercable Speaker(M)/Jack**
- No. 30225410..... 5 m



- OMNITRONIC Adaptercable 2xSpeaker(M) 2pin/4pin**
- No. 30225610..... 1 m



- OMNITRONIC Adaptercable Speaker(F)/XLR(F)**
- No. 30225600..... 1 m