

Z-Series II Spare Parts Price List

Z-1000II	220V-230V	Description	Price
Z10020LH		Side Panel/Left	
Z10020RH		Side Panel/Right	
Z100200L		Steel Case/Base	
Z100200H		Steel Case/Cover	
Z10020HB		Yoke	
B06606		P.C. Board (DMX)	
BOX016		Controller Case	
C00004		Buckle	
C00009		Pump Plate	
C00010		Nozzle Plate	
C00A01		Adaptor With Nut	
C01013		M8x12L Screw	
C01014		M8 Screw	
C02003		Magnetized Rubber	
C02031		Foot	
C02045		Washer	
C02143		Handle	
C02136		Tightening Screw	
C04001		Rocker Switch/Power	
C04004		Push Button/Fogging	
C04064		Pilot Lamp/Green	
C04084	C04082	Fuse	
C05016	C05005	Cable & Plug	
C05020		Cable For Remote Control	
C15Z1002-A	C15Z1002E-A	Temperature Fuse	
C15Z002-GHIJ	C15Z002E-GHIJ	Power Inlet Socket & Fuseholder	
D01003		M4x12L Screw	
D01004		M3x8L Screw	
D01051		M4x15L Screw	
D01101		M4x8L Screw	
D04103		P.C.B. Fastening Pin	
Z-10 Unit		Wired Remoted Control	
Z-1000II-P	Z-1000IIE-P	Pump (Group)	
Z-1000II-H	Z-1000IIE-H	Heater (Group)	
Z-1002CN		Heater Core	
Z-1000II-PCB	Z-1000IIE-PCB	P.C. Board (Main)	
Z-1002-TKC		Cap	
Z-1002-TK		Tank	