

A rubber cork was added as the picture shows below on the left. When in use, just leave the rubber cork on the left attached to the fixation.



After use or before moving, remove the cap and fix it on the left and use rubber cork as stopper for the fluid tank as below picture shows.

By doing this, users now are allowed to rotate the machine after fixing the rubber cork to the fluid tank.