


A

B

C

D

E



SPARE PARTS OF F-80Z (230V)

F850000L	Steel Case /Base	C00275	Copper Tube	C04081	Fuse (F3.15A/230V)
F850000H	Steel Case/Cover	C02003	Magnetized Rubber	C04521	Fuse Holder
F85000HB	Yoke	C02008	Tank	C05004	Cable & Plug(230V)
F7000002	Aluminium	C02029	Tank's Cap	C05024E	Cable For Remote Control
AW-027	Temperature Fuse	C02031	Foot	D01004	M3x8L Screw
BOX011	Controller Case	C02045	Washer	D01101	M4x8L Screw
C00002	Separat Plate	C02136	Tightening Screw	FCW-80Z	Wired Remote Controller
C00003	Trestle	C04002	Rocker Switch/Fogging	F-80E-H	Heater (Group)
C00004	Buckle	C04009	Pilot Lamp/Red	M24063	Motor
C00057	Copper Nut	C04040	Control Socket	U23007	Heater Element
C00058	Copper Nut Insert	C04073	Thermostat/220C		