

# eurolite® **SUPER STROBE 2700**

No. 52202174



[www.eurolite.de](http://www.eurolite.de)

## **ADDITIONAL INFORMATION** User manual version 4.0

### **EN** Interconnecting several devices

It is possible to connect 5 devices to a controller. First set the FLASH RATE control on all devices to minimum. Then connect the controller to the REMOTE CONTROL IN jack at the first device in the chain using a standard instrument cable with jack plugs. Finally, interconnect the REMOTE CONTROL IN/OUT jacks of the other devices via jack cables. All devices will now respond to the controller.

## **ERGÄNZENDE HINWEISE** Bedienungsanleitung Version 4.0

### **DE** Zusammenschalten von mehreren Geräten

Es lassen sich bis zu 5 Geräte zusammenschalten und mit einem analogen Controller steuern. Stellen Sie dazu den Regler FLASH RATE an den Geräten auf Minimum. Schließen Sie dann den Controller an die Buchse REMOTE CONTROL IN des ersten Geräts in der Kette über ein Klinkenkabel an. Verbinden Sie danach die Ein- und Ausgangsbuchsen REMOTE CONTROL IN/OUT der weiteren Geräte per Klinkenkabel. Die Geräte lassen sich nun mit dem Controller steuern.