



No. 6000450M with M20 inside thread
 No. 6000450N without inside thread

OMNITRONIC Speaker System-Stand Flange

Flange with/without M20 inside thread



No. 6000456E

OMNITRONIC GB-1 Stand Adapter

Gable to fix two speakers to one stand, distance from 310 - 490 mm



NEW

No. 60004611

OMNITRONIC BIB-1 Screen Adaptor for Loudspeaker Stands

Adaptor to attach LCD monitors (13-24") to loudspeaker stand



No. 60004613

GUIL PTR-33 Screen Adaptor for Loudspeaker Stands

Adaptor to attach tv screens to loudspeaker stands



NEW

No. 6000490A for two BS-1
 No. 6000490B for BS-2

OMNITRONIC Carrying Bag for two Speaker Stands BS-1



No. 6000490N

OMNITRONIC Carrying Bag for two Speaker Stands

Bag with 120 x 15 x 15 cm dimensions for speaker stands



No. 6000580N silver
 No. 6000580P black

OMNITRONIC Microphone Stand 85-157cm

Microphone stand with stable round base, extendible from 85-157 cm



No. 6000580R

OMNITRONIC Microphone Stand 100-170cm bk

Microphone stand with stable round base, extendible from 100-170 cm



No. 60005838

OMNITRONIC Microphone Tripod MS-2 with Boom bk

Microphone tripod with adjustable boom, max. height 220 cm



No. 60005839

OMNITRONIC Microphone Tripod MS-2A with Boom bk

Simple microphone tripod with adjustable boom, max. height 220 cm



No. 60005844

OMNITRONIC Microphone Tripod with Boom, PRO bk

PRO microphone tripod with boom, max. height 220 cm



No. 60005852

OMNITRONIC AP-1 Microphone Stand black

Low microphone stand with boom, height adjustable from 50 - 80 cm