



100V

OMNITRONIC PA Volume Controller, mono wh

PA volume controller with 24 V emergency priority relay

No. 80711001.....	5 W mono
No. 80711002.....	10 W mono
No. 80711003.....	20 W mono
No. 80711004.....	30 W mono
No. 80711005.....	45 W mono
No. 80711006.....	60 W mono
No. 80711007.....	120 W mono



100V

OMNITRONIC PA Volume Controller, mono bk

PA volume controller with 24 V emergency priority relay

No. 80711008.....	5 W mono
No. 80711009.....	10 W mono
No. 80711010.....	20 W mono
No. 80711011.....	30 W mono
No. 80711012.....	45 W mono
No. 80711013.....	60 W mono
No. 80711014.....	120 W mono



100V

OMNITRONIC PA Volume Controller mono sil

PA volume controller with 24 V emergency priority relay

No. 80711015.....	10 W mono
No. 80711016.....	45 W mono



100V

OMNITRONIC PA Volume Controller stereo wh

Stereo volume controller

No. 80711151.....	5 W stereo
No. 80711152.....	10 W stereo
No. 80711153.....	20 W stereo
No. 80711154.....	30 W stereo
No. 80711155.....	45 W stereo



100V

OMNITRONIC PA Volume Controller stereo bk

Stereo volume controller

No. 80711158.....	5 W stereo
No. 80711159.....	10 W stereo
No. 80711160.....	20 W stereo
No. 80711161.....	30 W stereo
No. 80711162.....	45 W stereo



100V

OMNITRONIC PA Volume Controller 10W stereo sil

Stereo volume controller

No. 80711165