

Soft-Case for Alto-Saxophone

Soft bag for alto-saxophone

Art. No.: 26600200

GTIN: 4026397192063



The article is no longer in our assortment.

Soft-Case for Alto-Saxophone

Soft bag for alto-saxophone

Art. No.: 26600200

GTIN: 4026397192063

Features:

- Nylon: material
- Color: blue
- High grade quality
- Padded and stable
- Compact and handy
- With handle
- This case guarantees robust protection and secure transport