

Halloween Dancing Singer, 145cm

The perfect hip swing for your Halloween party

Art. No.: 83316086

GTIN: 4026397633948



The article is no longer in our assortment.

Halloween Dancing Singer, 145cm

The perfect hip swing for your Halloween party

Art. No.: 83316086

GTIN: 4026397633948

Features:

- Hook arms and legs in the stand
- Activation of the animation and the sound effect by integrated microphone
- Optional with wired control possible
- Operation with three 1.5V AA batteries (not included in delivery)
- Powered by a battery/battery pack
- Sound effects
- Hips with motion effect
- Easy to assemble